

Remote Dry Contact Monitor

Troubleshooting Manual



730 The Kingsway Peterborough, ON K9J6W6 Canada
Tel: (705) 740 — 2010 Web: www.abmsensor.com
Fax: (705) 740 — 2563 E-mail: info@abmsensor.com

Remote Dry Contact Monitor Fails to Update Server

Remove the cover. Observe the LED.

Solid Red	Contact in Closed Position <i>Unless contact changes nothing will happen.</i>
Solid Green	Contact in Open Position <i>Unless contact changes nothing will happen.</i>
Blinking Yellow	Debouncing Contact for 5 Seconds <i>If contact has changed then the LED colour will also change to reflect the new state. The monitor will connect to the server if the new state has been programmed as an alarm state.</i>
Blinking Green	Connecting to server <i>The LED will usually flash green for 30 seconds to a minute.</i>
Blinking Red	Failed to connect to server - waiting 2 minutes <i>After 2 minutes the monitor will attempt to connect to the server again.</i>